

[Back](#)

## Lenovo Professional Wireless Keyboard - Hungarian (208)

4X30H56858



20 views

List Price (Tax excluded) [PRODUCT BROCHURE](#)

-

[Compare](#)

### FEATURE

### TECH SPECS

## Feature

### Product Description

The Lenovo Professional Wireless Keyboard offers a full-size keyboard design with a dedicated numeric keypad. The slim modern design has responsive keys and offers a premium typing experience. One touch dedicated media keys put the controls you use most at your fingertips. Connects easily with compatible devices with wireless nano USB receiver.

### Top Features

- 2.4 GHz wireless nano USB connection
- Full-size 3 zone keyboard layout with dedicated numeric keypad
- One-touch dedicated media controls
- Adjustable tilt leg and spill resistant keyboard design
- Supports Multiple Pairing Protocol for USB dongle replacement
- Up to 24 months battery life (may vary based on usage)

### More Information

[Technical Support](#)

## Tech Specs

EAN	0889561017654
UPC	889561017654
Warranty Type	Customer Replaceable Unit (CRU)
Warranty Period	2 Years

Maximum Relative Humidity (%)	95%
Minimum Relative Humidity (%)	20%
Maximum Operating Temperature	40 degrees Celsius (104 degrees Fahrenheit)
Minimum Operating Temperature	0 degrees Celsius (32 degrees Fahrenheit)
Package Type	Brown box
Hardware Requirements	Supported PC with USB port
Supported OS	Windows 7, Windows 8, Windows 8.1, Windows 10
Agency Approvals	ANATEL, BSMI, CB, CE, CITC, CNC, COFETEL, CTUVus, EAC, FCC, IC, ICASA, IDA, IFETEL, KCC, MIC, NCC, NTC, RCM, SRRRC, SUBTEL, TRA, TUV Mark, VCCI
Shipment Group	Lenovo Professional Wireless Keyboard Nano USB Receiver 2 AA batteries Set-up and information poster
Product Weight	700 g (1.54 lbs)
Height	20 mm (0.79 in)
Depth	450 mm (17.71 in)
Length	164 mm (6.46 in)
Water/Spill Resitance	Spill Resistant
Switch Type	Plunger/Rubber dome
Key Style	Low profile, island style keys
Tilt Adjustable	Yes

Color	Black
Hot Key	Dedicated multimedia keys
Language Layout	Hungarian (208)
Keyboard Layout	3-zone layout
Battery Life	Up to 24 months
Power Requirement	2 AA batteries
Connectivity	2.4 GHz Wireless via Nano USB
Brand	Lenovo

## Compatibility

### Operating System

OS Independent

### Compatible Machines

Description	ID	Footnote
10-ELLA-2 20E3 MT TX	20E3	
10-ELLA-2 20E4 MT RX	20E4	
100e AMD G3-82J7 - 100e Gen 3	82J7	371. Hotkey is not working under Chrome system
100e AMD G3-82J8 - 100e Gen 3	82J8	371. Hotkey is not working under Chrome system
100w AMD G3-82HY - 100w Gen 3	82HY	
100w AMD G3-82J0 - 100w Gen 3	82J0	
14e Chrome G2-82M1 - 14e Chromebook Gen 2	82M1	371. Hotkey is not working under Chrome system
14e Chrome G2-82M2 - 14e Chromebook Gen 2	82M2	371. Hotkey is not working under Chrome system

14w G2-82N8 - 14w Gen 2	82N8	
14w G2-82N9 - 14w Gen 2	82N9	
300e AMD 3rd Generation-82J9 - 300e Gen 3	82J9	
300e AMD 3rd Generation-82JA - 300e Gen 3	82JA	
300w AMD G3-82J1 - 300w Gen 3	82J1	
300w AMD G3-82J2 - 300w Gen 3	82J2	
500e G3-82JB - 500e Gen 3	82JB	371. Hotkey is not working under Chrome system
500e G3-82JC - 500e Gen 3	82JC	371. Hotkey is not working under Chrome system
500w G3-82J3 - 500w Gen 3	82J3	
500w G3-82J4 - 500w Gen 3	82J4	
A285-20MW MT	20MW	
A285-20MX MT	20MX	
A485-20MU MT	20MU	
A485-20MV MT	20MV	
C13 Yoga G1 Chromebook-20UX MT 2020	20UX	371. Hotkey is not working under Chrome system
C13 Yoga G1 Chromebook-20UY MT 2020	20UY	371. Hotkey is not working under Chrome system
E14 2nd Generation- 20TA MT 2020	20TA	

E14 2nd Generation- 20TB MT 2020	20TB	
E14 2nd Generation- ARE-20T6 MT 2020	20T6	
E14 2nd Generation- ARE-20T7 MT 2020	20T7	
E14 AMD 3rd Generation-20Y7 - E14 AMD Gen 3	20Y7	
E14 AMD 3rd Generation-20YD - E14 AMD Gen 3	20YD	
E14 AMD 3rd Generation-20YE - E14 AMD Gen 3	20YE	
E14 AMD 3rd Generation-20YF - E14 AMD Gen 3	20YF	
E14-IML-20RA MT	20RA	
E14-IML-20RB MT	20RB	
E15 2nd Generation- ARE-20T8 MT 2020	20T8	
E15 2nd Generation- ARE-20T9 MT 2020	20T9	
E15 AMD 3rd Generation-20YG - E15 AMD Gen 3	20YG	
E15 AMD 3rd Generation-20YH - E15 AMD Gen 3	20YH	
E15 AMD 3rd Generation-20YJ - E15 AMD Gen 3	20YJ	

E15 AMD 3rd Generation-20YK - E15 AMD Gen 3	20YK	
E15 G2-20TD MT 2020	20TD	
E15 G2-20TE MT 2020	20TE	
E15-IML-20RD MT	20RD	
E15-IML-20RE MT	20RE	
E450 Sub Series-20DC	20DC	
E450 Sub Series-20DD	20DD	
E455 Sub Series-20DE	20DE	
E460-20ET MT	20ET	
E460-20EU MT	20EU	
E465-20EX MT	20EX	
E470-20H1 MT	20H1	
E470-20H2 MT	20H2	
E475-20H4 MT	20H4	
E480-20KN MT	20KN	
E480-20KQ MT	20KQ	
E490-20N8 MT	20N8	
E490-20N9 MT	20N9	
E490s-20NG MT	20NG	
E495-20NE MT	20NE	
E550 Sub Series-20DF	20DF	
E550 Sub Series-20DG	20DG	
E550c Sub Series-20E0 MT	20E0	

E555 Sub Series-20DH	20DH	
E560-20EV MT	20EV	
E560-20EW MT	20EW	
E560p-20G5 MT	20G5	
E565-20EY MT	20EY	
E570-20H5 MT	20H5	
E570-20H6 MT	20H6	
E575-20H8 MT	20H8	
E580-20KS MT	20KS	
E580-20KT MT	20KT	
E590-20NB MT	20NB	
E590-20NC MT	20NC	
E595-20NF MT	20NF	
Helix-20CG MT	20CG	
Helix-20CH MT	20CH	
IP Flex 3 Chrome 11IJL6-82N3 - IP Flex 3 Chrome 11IJL6	82N3	
IP Flex 3 Chrome 11M836-82KM - IP Flex 3 Chrome 11M836	82KM	
IP Flex 5 Chrome 13ITL6-82M7 - IP Flex 5 Chrome 13ITL6	82M7	
IdeaPad 1 14ADA7- 82R0 - IdeaPad 1 14ADA7	82R0	
IdeaPad 1 14IJL7-82LV - IdeaPad 1 14IJL7	82LV	

IdeaPad 1 15ADA7- 82R1 - IdeaPad 1 15ADA7	82R1	
IdeaPad 1 15IJL7-82LX - IdeaPad 1 15IJL7	82LX	
IdeaPad 3 14ADA05- MT 81W0	81W0	
IdeaPad 3 14ADA6- 82KQ - IdeaPad 3 14ADA6	82KQ	
IdeaPad 3 14ARE05- MT 81W3	81W3	
IdeaPad 3 14IGL05-MT 81WH	81WH	
IdeaPad 3 15ADA6- 82KR - IdeaPad 3 15ADA6	82KR	
IdeaPad 3 15ALC6- 82KU - IdeaPad 3 15ALC6	82KU	
IdeaPad 3 15ALC6- 82MF - IdeaPad 3 15ALC6	82MF	
IdeaPad 3 15ARE05- MT 81W4	81W4	
IdeaPad 3 15IGL05-MT 81WQ	81WQ	
IdeaPad 3 15IGL05-MT 82BU	82BU	
IdeaPad 3 15ITL06- 82MD - IdeaPad 3 15ITL6	82MD	
IdeaPad 3 15ITL06-MT 82H8	82H8	
IdeaPad 3 17ADA05- MT 81W2	81W2	



IdeaPad 3 17ADA6-82KS - IdeaPad 3 17ADA6	82KS	
IdeaPad 3 17ARE05-MT 81W5	81W5	
IdeaPad 3 Chrome 14APO6-MT 82MY	82MY	
IdeaPad 3 Chrome 14M836-82KN - IdeaPad 3 Chrome 14M836	82KN	
IdeaPad 3 Chrome 15IJL6-82N4 - IdeaPad 3 Chrome 15IJL6	82N4	
IdeaPad 5 15IIL05-MT 81YK	81YK	
IdeaPad 5 Chrome 14ITL6-82M8 - IdeaPad 5 Chrome 14ITL6	82M8	371. Hotkey is not working under Chrome system
IdeaPad 5G 14Q8X05-82KF - IdeaPad 5G 14Q8X05	82KF	
IdeaPad Flex 3 11ADA05-MT 82G4	82G4	
IdeaPad Flex 3 11IGL05-MT 82B2	82B2	
IdeaPad Flex 3 CB 11IGL05-MT 82BB	82BB	
IdeaPad Flex 3 CB 11M735-MT 82HG	82HG	
IdeaPad Flex 5 14ALC05-82HU - IdeaPad Flex 5 14ALC05	82HU	

IdeaPad Flex 5 14IIL05- MT 81WS	81WS	
IdeaPad Flex 5 14IIL05- MT 81X1	81X1	
IdeaPad Flex 5 14ITL05-82HS - IdeaPad Flex 5 14ITL05	82HS	
IdeaPad Flex 5 14ITL05-82LT - IdeaPad Flex 5 14ITL05	82LT	
IdeaPad Flex 5 15ALC05-82HV - IdeaPad Flex 5 15ALC05	82HV	
IdeaPad Flex 5 15IIL05- MT 81X3	81X3	
IdeaPad Flex 5 15ITL05-82HT - IdeaPad Flex 5 15ITL05	82HT	
IdeaPad Flex 5 CB 13IML05-MT 82B8	82B8	
IdeaPad Flex 5-14ARE- 05-MT 81X2	81X2	
IdeaPad Gaming 3 15ACH6-82K2 - IdeaPad Gaming 3 15ACH6	82K2	
IdeaPad Gaming 3 15ACH6-82MJ - IdeaPad Gaming 3 15ACH6	82MJ	
IdeaPad Gaming 3 15IHU6-82K1 - IdeaPad Gaming 3 15IHU6	82K1	

IdeaPad Gaming 3 15IHU6-82MG - IdeaPad Gaming 3 15IHU6	82MG	
IdeaPad Slim 7 Pro 14IHU5-82QT - IdeaPad Slim 7 Pro 14IHU5	82QT	
IdeaPad Slim 7 Pro 16ACH6-82QR - IdeaPad Slim 7 Pro 16ACH6	82QR	
L13 Clam 2nd Generation-20VH MT 2020	20VH	
L13 Clam 2nd Generation-20VJ MT 2020	20VJ	
L13 Clam AMD G2- 21AB - L13 Clam Gen 2	21AB	
L13 Clam AMD G2- 21AC - L13 Clam Gen 2	21AC	
L13 Clam-20R3 MT	20R3	
L13 Clam-20R4 MT	20R4	
L13 Yoga 2nd Generation-20VK MT 2020	20VK	
L13 Yoga 2nd Generation-20VL MT 2020	20VL	
L13 Yoga AMD G2- 21AD - L13 Yoga Gen 2	21AD	
L13 Yoga AMD G2- 21AE - L13 Yoga Gen 2	21AE	
L13 Yoga-20R5 MT	20R5	

L13 Yoga-20R6 MT	20R6	
L14 AMD G1-20U5 MT 2020	20U5	
L14 AMD G1-20U6 MT 2020	20U6	
L14 AMD G2-20X5 - L14 Gen 2	20X5	
L14 AMD G2-20X6 - L14 Gen 2	20X6	
L14 G2-20X1 - L14 Gen 2	20X1	
L14 G2-20X2 - L14 Gen 2	20X2	
L15 AMD G1-20U7 MT 2020	20U7	
L15 AMD G1-20U8 MT 2020	20U8	
L15 AMD G2-20X7 - L15 Gen 2	20X7	
L15 AMD G2-20X8 - L15 Gen 2	20X8	
L15 G2-20X3 - L15 Gen 2	20X3	
L15 G2-20X4 - L15 Gen 2	20X4	
L380-20M5 MT	20M5	
L380-20M6 MT	20M6	
L380-20M7 MT	20M7	
L380-20M8 MT	20M8	
L390-20NR MT	20NR	
L390-20NS MT	20NS	
L390-20NT MT	20NT	

L390-20NU MT	20NU	
L450-20DS MT	20DS	
L450-20DT MT	20DT	
L460-20FU MT	20FU	
L460-20FV MT	20FV	
L470-20J4 MT	20J4	
L470-20J5 MT	20J5	
L470-20JU MT	20JU	
L470-20JV MT	20JV	
L480-20LS MT	20LS	
L480-20LT MT	20LT	
L490-20Q5 MT	20Q5	
L490-20Q6 MT	20Q6	
L560-20F1 MT	20F1	
L560-20F2 MT	20F2	
L570-20J8 MT	20J8	
L570-20J9 MT	20J9	
L570-20JQ MT	20JQ	
L570-20JR MT	20JR	
L580-20LW MT	20LW	
L580-20LX MT	20LX	
L590-20Q7 MT	20Q7	
L590-20Q8 MT	20Q8	
Legion 5 15ACH6- 82JW - Legion 5 15ACH6	82JW	

Legion 5 15ACH6- 82QJ - Legion 5 15ACH6	82QJ	
Legion 5 15ACH6A- 82NW - Legion 5 15ACH6A	82NW	
Legion 5 15IAH7-82RC - Legion 5 15IAH7	82RC	
Legion 5 15IAH7H- 82RB - Legion 5 15IAH7H	82RB	
Legion 5 15IMH6-82NL - Legion 5 15IMH6	82NL	
Legion 5 15ITH6-82JK - Legion 5 15ITH6	82JK	
Legion 5 15ITH6H- 82JH - Legion 5 15ITH6H	82JH	
Legion 5 15ITH6H- 82MH - Legion 5 15ITH6H	82MH	
Legion 5 17ACH6- 82K0 - Legion 5 17ACH6	82K0	
Legion 5 17ITH6-82JN - Legion 5 17ITH6	82JN	
Legion 5 17ITH6H- 82JM - Legion 5 17ITH6H	82JM	
Legion 5 Pro 16ACH6- 82JS - Legion 5 Pro 16ACH6	82JS	
Legion 5 Pro 16IAH7- 82S0 - Legion 5 Pro 16IAH7	82S0	

Legion 5 Pro 16IAH7H- 82RF - Legion 5 Pro 16IAH7H	82RF	
Legion 5 Pro 16ITH6- 82JF - Legion 5 Pro 16ITH6	82JF	
Legion 5 Pro 16ITH6H- 82JD - Legion 5 Pro 16ITH6H	82JD	
Legion 7 16ITHg6- 82K6 - Legion 7 16ITHg6	82K6	
Legion S7 15ACH6- 82K8 - Legion S7 15ACH6	82K8	
Lenovo 100e 2nd Gen- 81M8 MT	81M8	371. Hotkey is not working under Chrome system
Lenovo 100e 2nd Gen- 82GJ MT 2020	82GJ	
Lenovo 100e 2nd Gen_BRL-82LR MT 2020	82LR	371. Hotkey is not working under Chrome system
Lenovo 100e Chromebook 2nd Gen AST-82CD MT 2020	82CD	371. Hotkey is not working under Chrome system
Lenovo 100e Chromebook 2nd Gen AST_BRL-82LS MT 2020	82LS	371. Hotkey is not working under Chrome system
Lenovo 100e Chromebook 2nd Gen MTK 2-82Q3 - Lenovo 100e Chrome 2nd Gen MTK 2	82Q3	371. Hotkey is not working under Chrome system

Lenovo 100e Chromebook 2nd Gen MTK-81QB MT	81QB	371. Hotkey is not working under Chrome system
Lenovo 100e Chromebook 2nd Gen- 81MA MT	81MA	371. Hotkey is not working under Chrome system
Lenovo 100e Chromebook-MT 81ER	81ER	371. Hotkey is not working under Chrome system
Lenovo 14e Chromebook-81MH MT	81MH	371. Hotkey is not working under Chrome system
Lenovo 14w-81MQ MT	81MQ	371. Hotkey is not working under Chrome system
Lenovo 300e 2nd Gen- 81M9 MT	81M9	371. Hotkey is not working under Chrome system
Lenovo 300e 2nd Gen- 82GK MT 2020	82GK	
Lenovo 300e Chromebook 2nd Gen AST-82CE MT 2020	82CE	371. Hotkey is not working under Chrome system
Lenovo 300e Chromebook 2nd Gen MTK-81QC MT	81QC	371. Hotkey is not working under Chrome system
Lenovo 300e Chromebook 2nd Gen- 81MB MT	81MB	371. Hotkey is not working under Chrome system
Lenovo 300e Chromebook-81H0 MT	81H0	371. Hotkey is not working under Chrome system
Lenovo 500e Chromebook 2nd Gen- 81MC MT	81MC	371. Hotkey is not working under Chrome system
Lenovo 500e Chromebook-MT 81ES	81ES	371. Hotkey is not working under Chrome system
Lenovo 5G 14Q8CX05- MT 82AK	82AK	
Lenovo B320-14IKB- MT 81CC	81CC	



Lenovo B330-15IKB-MT 81G7	81G7	
Lenovo B330-15IKBR-MT 81M1	81M1	
Lenovo FLEX 6-11IGM-MT 81A7	81A7	
Lenovo IdeaPad C340-14API-MT 81N6	81N6	
Lenovo IdeaPad C340-14IML-MT 81TK	81TK	
Lenovo IdeaPad C340-14IWL-MT 81N4	81N4	
Lenovo IdeaPad C340-14IWL-MT 81RL	81RL	
Lenovo IdeaPad C340-15IIL-MT 81XJ	81XJ	
Lenovo IdeaPad C340-15IML-MT 81TL	81TL	
Lenovo IdeaPad C340-15IWL-MT 81N5	81N5	
Lenovo IdeaPad FLEX-14API-MT 81SS	81SS	
Lenovo IdeaPad FLEX-14IML-MT 81XG	81XG	
Lenovo IdeaPad FLEX-14IWL-MT 81SQ	81SQ	
Lenovo IdeaPad FLEX-15IIL-MT 81XK	81XK	
Lenovo IdeaPad FLEX-15IML-MT 81XH	81XH	
Lenovo IdeaPad FLEX-15IWL-MT 81SR	81SR	
Lenovo IdeaPad S540-13ARE-MT 82DL	82DL	
Lenovo MIIX 325-10ICR-MT 81B9	81B9	

Lenovo MIIX 510-12IKB-MT 80XE	80XE	
Lenovo MIIX 520-12IKB-20M3 MT	20M3	
Lenovo MIIX 520-12IKB-20M4 MT	20M4	
Lenovo MIIX 520-12IKB-MT 81CG	81CG	
Lenovo MIIX 700-12ISK-MT 80QL	80QL	
Lenovo MIIX 710-12IKB-MT 80W1	80W1	
Lenovo MIIX 720-12IKB-MT 80VV	80VV	
Lenovo Miix 630-12Q35-MT 81F1	81F1	
Lenovo S200-10HQ	10HQ	
Lenovo S200-10HR	10HR	
Lenovo S200z-10HA	10HA	
Lenovo S200z-10K1	10K1	
Lenovo S200z-10K4	10K4	
Lenovo S200z-10K5	10K5	
Lenovo S400z-10HB	10HB	
Lenovo S400z-10K2	10K2	
Lenovo S405z-10HD	10HD	
Lenovo S500-10HS	10HS	
Lenovo S500-10HV	10HV	
Lenovo S500-10JH	10JH	
Lenovo S500-10JJ	10JJ	
Lenovo S500-10JK	10JK	

Lenovo S500-10JL	10JL	
Lenovo S500z-10HC	10HC	
Lenovo S500z-10K3	10K3	
Lenovo S510-10KW	10KW	
Lenovo S510-10KX	10KX	
Lenovo S510-10KY	10KY	
Lenovo S510-10L0	10L0	
Lenovo S510-10L3	10L3	
Lenovo S510-10L4	10L4	
Lenovo S510-10L7	10L7	
Lenovo S510-10L8	10L8	
Lenovo S510-10LB	10LB	
Lenovo S510-10LC	10LC	
Lenovo S510-10LF	10LF	
Lenovo S510-10LG	10LG	
Lenovo Tablet 10-20L3 MT	20L3	
Lenovo Tablet 10-20L4 MT	20L4	
Lenovo ThinkBook 13s- IML-MT 20RR	20RR	
Lenovo ThinkBook 14- IIL-MT 20SL	20SL	
Lenovo ThinkBook 14- IML-MT 20RV	20RV	
Lenovo ThinkBook 14s Yoga ITL-MT 20WE	20WE	
Lenovo ThinkBook 14s- IML-MT 20RS	20RS	

Lenovo ThinkBook 15- IIL-MT 20SM	20SM	
Lenovo ThinkBook 15- IML-MT 20RW	20RW	
Lenovo ThinkBook 15p- IMH-MT 20V3	20V3	
Lenovo ThinkBook Plus-MT 20TG	20TG	
Lenovo V130-14IGM- MT 81HM	81HM	
Lenovo V130-14IKB- MT 81HQ	81HQ	
Lenovo V130-15IGM- MT 81HL	81HL	
Lenovo V130-15IKB- MT 81HN	81HN	
Lenovo V130-20IGM AIO-10RX	10RX	
Lenovo V14 G1 IML- 82NA - Lenovo V14 G1 IML	82NA	
Lenovo V14 G2 ALC- 82KC - Lenovo V14- ALC	82KC	
Lenovo V14 G2 IJL- 82QX - Lenovo V14 G2 IJL	82QX	
Lenovo V14-ADA-MT 82C6	82C6	
Lenovo V14-ARE-MT 82DQ	82DQ	
Lenovo V14-IGL-MT 82C2	82C2	
Lenovo V14-IIL-MT 82C4	82C4	

Lenovo V14-IKB-MT 81YA	81YA	
Lenovo V14-ITL-82KA - Lenovo V14-ITL	82KA	
Lenovo V14-IWL-MT 81YB	81YB	
Lenovo V140-15IWL- MT 81K6	81K6	
Lenovo V145-14AST- MT 81MS	81MS	
Lenovo V145-15AST- MT 81MT	81MT	
Lenovo V15 G1 IML(Brazil)-82NQ - Lenovo V15 G1 IML(Brazil)	82NQ	
Lenovo V15 G1 IML- 82NB - Lenovo V15 G1 IML	82NB	
Lenovo V15 G2 ALC- 82KD - Lenovo V15- ALC	82KD	
Lenovo V15 G2 IJL- 82QY - Lenovo V15 G2 IJL	82QY	
Lenovo V15-ADA-MT 82C7	82C7	
Lenovo V15- IGL(Brazil)-82NN - Lenovo V15-IGL(Brazil)	82NN	
Lenovo V15-IGL-MT 82C3	82C3	
Lenovo V15-IIL-MT 82C5	82C5	
Lenovo V15-IKB-MT 81YD	81YD	

Lenovo V15-ITL-82KB - Lenovo V15-ITL	82KB	
Lenovo V15-IWL-MT 81YE	81YE	
Lenovo V17 G2 ITL- 82NX - Lenovo V17 G2 ITL	82NX	
Lenovo V17-IIL-MT 82GX	82GX	
Lenovo V30a-22IIL- 11LC	11LC	
Lenovo V30a-22IIL- 11LD	11LD	
Lenovo V30a-22IML- 11FV	11FV	
Lenovo V30a-22IML- 11FW	11FW	
Lenovo V30a-24IIL- 11LA	11LA	
Lenovo V30a-24IIL- 11LB	11LB	
Lenovo V30a-24IML- 11FT	11FT	
Lenovo V30a-24IML- 11FU	11FU	
Lenovo V310z-10QG	10QG	
Lenovo V310z-10QH	10QH	
Lenovo V320-10N5	10N5	
Lenovo V320-10N6	10N6	
Lenovo V320-MT 81AH	81AH	
Lenovo V320-MT 81CN	81CN	

Lenovo V330-14ARR- MT 81B1	81B1	
Lenovo V330-15IGM Desktop-10TS	10TS	
Lenovo V330-20ICB AIO-10UK	10UK	
Lenovo V330-20ICB AIO-10UL	10UL	
Lenovo V330-MT 81AW	81AW	
Lenovo V330-MT 81AX	81AX	
Lenovo V330-MT 81AY	81AY	
Lenovo V330-MT 81B0	81B0	
Lenovo V35s-07ADA- 11HE	11HE	
Lenovo V35s-07ADA- 11HF	11HF	
Lenovo V35s-07ADA- 11HQ	11HQ	
Lenovo V35s-07ADA- 11HR	11HR	
Lenovo V410z-10QV	10QV	
Lenovo V410z-10QW	10QW	
Lenovo V410z-10R5	10R5	
Lenovo V410z-10R6	10R6	
Lenovo V50a-22IMB- 11FN	11FN	
Lenovo V50a-22IMB- 11FQ	11FQ	
Lenovo V50a-22IMB- 11FR	11FR	
Lenovo V50a-22IMB- 11FS	11FS	

Lenovo V50a-24IMB- 11FJ	11FJ	
Lenovo V50a-24IMB- 11FK	11FK	
Lenovo V50a-24IMB- 11FL	11FL	
Lenovo V50a-24IMB- 11FM	11FM	
Lenovo V50s-07IMB- 11EE	11EE	
Lenovo V50s-07IMB- 11EF	11EF	
Lenovo V50s-07IMB- 11HA	11HA	
Lenovo V50s-07IMB- 11HB	11HB	
Lenovo V50t Gen 2- 13IOB-11QB - Lenovo V50t Gen 2-13IOB	11QB	
Lenovo V50t Gen 2- 13IOB-11QC - Lenovo V50t Gen 2-13IOB	11QC	
Lenovo V50t Gen 2- 13IOB-11QD - Lenovo V50t Gen 2-13IOB	11QD	
Lenovo V50t Gen 2- 13IOB-11QE - Lenovo V50t Gen 2-13IOB	11QE	
Lenovo V50t-13IMB- 11EC	11EC	
Lenovo V50t-13IMB- 11ED	11ED	
Lenovo V50t-13IMB- 11HC	11HC	
Lenovo V50t-13IMB- 11HD	11HD	



Lenovo V510z-10NH	10NH	
Lenovo V520-10NK	10NK	
Lenovo V520-10NL	10NL	
Lenovo V520s-10NM	10NM	
Lenovo V520s-10NN	10NN	
Lenovo V525-10N7	10N7	
Lenovo V525-10N8	10N8	
Lenovo V530-15ARR Desktop-10V3	10V3	
Lenovo V530-15ARR Desktop-10Y3	10Y3	
Lenovo V530-15ICB Desktop-10TV	10TV	
Lenovo V530-15ICB Desktop-10TW	10TW	
Lenovo V530-15ICR Desktop-11BG	11BG	
Lenovo V530-15ICR Desktop-11BH	11BH	
Lenovo V530-22ICB AIO-10US	10US	
Lenovo V530-22ICB AIO-10UT	10UT	
Lenovo V530-22ICB AIO-10UU	10UU	
Lenovo V530-22ICB AIO-10UV	10UV	
Lenovo V530S-07ICB Desktop-10TX	10TX	
Lenovo V530S-07ICB Desktop-10TY	10TY	
Lenovo V530S-07ICR Desktop-11BL	11BL	

Lenovo V530S-07ICR Desktop-11BM	11BM	
Lenovo V540-24IWL AIO-10YS	10YS	
Lenovo V55t Gen 2- 13ACN-11RM - Lenovo V55t Gen 2-13ACN	11RM	
Lenovo V55t Gen 2- 13ACN-11RN - Lenovo V55t Gen 2-13ACN	11RN	
Lenovo V55t Gen 2- 13ACN-11RQ - Lenovo V55t Gen 2-13ACN	11RQ	
Lenovo V55t Gen 2- 13ACN-11RR - Lenovo V55t Gen 2-13ACN	11RR	
Lenovo V55t Gen 2- 13ACN-11VS-Lenovo V55t Gen 2-13ACN	11VS	
Lenovo V55t Gen 2- 13ACN-11VT-Lenovo V55t Gen 2-13ACN	11VT	
Lenovo V55t Gen 2- 13ACN-11VU-Lenovo V55t Gen 2-13ACN	11VU	
Lenovo V55t Gen 2- 13ACN-11VV-Lenovo V55t Gen 2-13ACN	11VV	
Lenovo V55t-15API- 11CB	11CB	
Lenovo V55t-15API- 11CC	11CC	
Lenovo V55t-15ARE- 11KF	11KF	
Lenovo V55t-15ARE- 11KG	11KG	

Lenovo V55t-15ARE-11KH	11KH	
Lenovo V55t-15ARE-11KJ	11KJ	
Lenovo V720-14-MT 80Y1	80Y1	
Lenovo V730-13-MT 81AV	81AV	
Lenovo ideapad 2in1 14-MT 81CW	81CW	
Lenovo ideapad D330-10IGL-82H0 MT 2020	82H0	
Lenovo ideapad D330-10IGM-MT 81MD	81MD	
Lenovo ideapad FLEX 5-1470-MT 80XA	80XA	
Lenovo ideapad FLEX 5-1470-MT 81C9	81C9	
Lenovo ideapad FLEX 5-1570-MT 80XB	80XB	
Lenovo ideapad FLEX 5-1570-MT 81CA	81CA	
Lenovo ideapad FLEX 6-14ARR-MT 81HA	81HA	
Lenovo ideapad FLEX 6-14IKB-MT 81EM	81EM	
Lenovo ideapad MIIX 510-12ISK-MT 80U1	80U1	
P1 2nd Generation-20QT MT	20QT	
P1 2nd Generation-20QU MT	20QU	
P1 G4-20Y3 - P1 Gen 4	20Y3	
P1 G4-20Y4 - P1 Gen 4	20Y4	
P1-20MD MT	20MD	

P1-20ME MT	20ME	
P14s 2nd Generation- 20VX MT 2021	20VX	
P14s 2nd Generation- 20VY MT 2021	20VY	
P14s AMD G1-20Y1 - P14s AMD Gen 1	20Y1	
P14s AMD G1-20Y2 - P14s AMD Gen 1	20Y2	
P14s AMD G2-21A0 - P14s AMD Gen 2	21A0	
P14s AMD G2-21A1 - P14s AMD Gen 2	21A1	
P15 G2-20YQ - P15 Gen 2	20YQ	
P15 G2-20YR - P15 Gen 2	20YR	
P15s 1st Generation- 20T4 MT 2020	20T4	
P15s 1st Generation- 20T5 MT 2020	20T5	
P15s 2nd Generation- 20W6 - P15s Gen 2	20W6	
P15s 2nd Generation- 20W7 - P15s Gen 2	20W7	
P15v G2-21A9 - P15v Gen 2	21A9	
P15v G2-21AA - P15v Gen 2	21AA	
P17 G2-20YU - P17 Gen 2	20YU	
P17 G2-20YV - P17 Gen 2	20YV	
P40 Yoga-20GQ MT	20GQ	
P40 Yoga-20GR MT	20GR	

P43s-20RH MT	20RH	
P43s-20RJ MT	20RJ	
P50-20EN MT	20EN	
P50-20EQ MT	20EQ	
P50s-20FK MT	20FK	
P50s-20FL MT	20FL	
P51-20HH MT	20HH	
P51-20HJ MT	20HJ	
P51s-20HB MT	20HB	
P51s-20HC MT	20HC	
P51s-20JY MT	20JY	
P51s-20K0 MT	20K0	
P52-20M9 MT	20M9	
P52-20MA MT	20MA	
P52s-20LB MT	20LB	
P52s-20LC MT	20LC	
P53-20QN MT	20QN	
P53-20QQ MT	20QQ	
P53s-20N6 MT	20N6	
P53s-20N7 MT	20N7	
P70-20ER MT	20ER	
P70-20ES MT	20ES	
P71-20HK MT	20HK	
P71-20HL MT	20HL	
P72-20MB MT	20MB	

P72-20MC MT	20MC	
S1 4th Gen-STORM-3.0 20LK MT	20LK	
S100-20C0 MT	20C0	
S100-20CD MT	20CD	
S3-20G0 MT	20G0	
S3-20G1 MT	20G1	
S5-20G4 MT	20G4	
S5-20JA MT	20JA	
T14 2nd Generation- 20W0 MT 2021	20W0	
T14 2nd Generation- 20W1 MT 2021	20W1	
T14 2nd Generation- 20W2 MT 2021 HC	20W2	
T14 2nd Generation- 20W3 MT 2021 HC	20W3	
T14 AMD G1-20UD MT 2020	20UD	
T14 AMD G1-20UE MT 2020	20UE	
T14 AMD G2-20XK - T14 AMD Gen 2	20XK	
T14 AMD G2-20XL - T14 AMD Gen 2	20XL	
T14s 2nd Generation- 20WM - T14s Gen 2	20WM	
T14s 2nd Generation- 20WN - T14s Gen 2	20WN	
T14s AMD G1-20UH MT 2020	20UH	
T14s AMD G1-20UJ MT 2020	20UJ	

T14s AMD G2-20XF - T14s AMD Gen 2	20XF	
T14s AMD G2-20XG - T14s AMD Gen 2	20XG	
T15 2nd Generation- 20W4 - T15 Gen 2	20W4	
T15 2nd Generation- 20W5 - T15 Gen 2	20W5	
T15g G2-20YS - T15g Gen 2	20YS	
T15g G2-20YT - T15g Gen 2	20YT	
T15p G2-21A7 - T15p Gen 2	21A7	
T15p G2-21A8 - T15p Gen 2	21A8	
T450-20BU MT	20BU	
T450-20BV MT	20BV	
T450-20DJ	20DJ	
T450s-20BW MT	20BW	
T450s-20BX MT	20BX	
T460-20FM MT	20FM	
T460-20FN MT	20FN	
T460p-20FW MT	20FW	
T460p-20FX MT	20FX	
T460s-20F9 MT	20F9	
T460s-20FA MT	20FA	
T470-20HD MT	20HD	
T470-20HE MT	20HE	
T470-20JM MT	20JM	

T470-20JN MT	20JN	
T470p-20J6 MT	20J6	
T470p-20J7 MT	20J7	
T470s-20HF MT	20HF	
T470s-20HG MT	20HG	
T470s-20JS MT	20JS	
T470s-20JT MT	20JT	
T480-WINDU-2.0 20L5 MT	20L5	
T480-WINDU-2.0 20L6 MT	20L6	
T480s-KOLAR-1.0 20L7 MT	20L7	
T480s-KOLAR-1.0 20L8 MT	20L8	
T490-20N2 MT	20N2	
T490-20N3 MT	20N3	
T490-20Q9 MT	20Q9	
T490-20QH MT	20QH	
T490-20RX MT	20RX	
T490-20RY MT	20RY	
T490s-20NX MT	20NX	
T490s-20NY MT	20NY	
T495-20NJ MT	20NJ	
T495-20NK MT	20NK	
T495s-20QJ MT	20QJ	
T495s-20QK MT	20QK	



T550-20CJ MT	20CJ	
T550-20CK MT	20CK	
T560-20FH MT	20FH	
T560-20FJ MT	20FJ	
T570-20H9 MT	20H9	
T570-20HA MT	20HA	
T570-20JW MT	20JW	
T570-20JX MT	20JX	
T580-20L9 MT	20L9	
T580-20LA MT	20LA	
T590-20N4 MT	20N4	
T590-20N5 MT	20N5	
TP25-20K7 MT	20K7	
Tablet 10-20C1 MT	20C1	
Tablet 10-20C3 MT	20C3	
ThinkBook 13s 2nd Generation-ITL-MT 20V9	20V9	
ThinkBook 13s G2 ARE-MT code	20WC	
ThinkBook 13s G3 ACN-20YA - ThinkBook 13s G3 ACN	20YA	
ThinkBook 13s G4 IAP- 21AR - ThinkBook 13s G4 IAP	21AR	
ThinkBook 13x ITG- 20WJ - ThinkBook 13x ITG	20WJ	

ThinkBook 14 2nd Generation-ARE-MT 20VF	20VF	
ThinkBook 14 2nd Generation-ITL-MT 20VD	20VD	
ThinkBook 14 3rd Generation - ACL-MT 21A2 ThinkBook 14 G3 ACL	21A2	
ThinkBook 14 G3 ITL- 21A3 - ThinkBook 14 G3 ITL	21A3	
ThinkBook 14p G2 ACH-20YN - ThinkBook 14p G2 ACH	20YN	
ThinkBook 14s 2nd Generation-ITL-MT 20VA	20VA	
ThinkBook 15 2nd Generation-ARE-MT 20VG	20VG	
ThinkBook 15 2nd Generation-ITL-MT 20VE	20VE	
ThinkBook 15 3rd Generation - ACL-MT 21A4 ThinkBook 15 G3 ACL	21A4	
ThinkBook 15 G3 ITL- 21A5 - ThinkBook 15 G3 ITL	21A5	
ThinkBook 15p G2 ITH- 21B1 - ThinkBook 15p G2 ITH	21B1	

ThinkBook 16p G2 ACH-20YM - ThinkBook 16p G2 ACH	20YM	
ThinkBook Plus G2 ITG-20WH - ThinkBook Plus G2 ITG	20WH	
ThinkCentre Chromebox-10H2	10H2	
ThinkCentre Chromebox-10H3	10H3	
ThinkCentre Chromebox-10H4	10H4	
ThinkCentre Chromebox-10H5	10H5	
ThinkCentre Chromebox-10H6	10H6	
ThinkCentre Chromebox-10H8	10H8	
ThinkCentre Chromebox-10H9	10H9	
ThinkCentre E63z- 10D4	10D4	
ThinkCentre E63z- 10D5	10D5	
ThinkCentre E63z- 10D6	10D6	
ThinkCentre E63z- 10D7	10D7	
ThinkCentre E63z- 10E0	10E0	
ThinkCentre E63z- 10E1	10E1	
ThinkCentre E63z- 10E2	10E2	

ThinkCentre E63z- 10E3	10E3	
ThinkCentre E63z- 10EL	10EL	
ThinkCentre E74-10KR	10KR	
ThinkCentre E74-10KS	10KS	
ThinkCentre E74s- 10KT	10KT	
ThinkCentre E74z- 10LN	10LN	
ThinkCentre E76p- 11BR	11BR	
ThinkCentre E76x- 11BA	11BA	
ThinkCentre E77s- 12A4-ThinkCentre E77s	12A4	
ThinkCentre E95-10RJ	10RJ	
ThinkCentre E95z- 10RK	10RK	
ThinkCentre E96x- 11BB	11BB	
ThinkCentre E97s- 12AY - ThinkCentre E97s	12AY	
ThinkCentre E98-11QF - ThinkCentre E98	11QF	
ThinkCentre Edge 62z- 2117	2117	
ThinkCentre Edge 62z- 2118	2118	
ThinkCentre Edge 73z- 10BD	10BD	
ThinkCentre Edge 93Z- 10B8	10B8	

ThinkCentre Edge 93Z- 10B9	10B9	
ThinkCentre M600- 10G8	10G8	
ThinkCentre M600- 10G9	10G9	
ThinkCentre M600- 10GA	10GA	
ThinkCentre M600- 10GB	10GB	
ThinkCentre M600- 10GC	10GC	
ThinkCentre M600- 10GD	10GD	
ThinkCentre M600- 10GE	10GE	
ThinkCentre M600- 10GF	10GF	
ThinkCentre M600- 10GG	10GG	
ThinkCentre M600- 10GH	10GH	
ThinkCentre M600- 10GJ	10GJ	
ThinkCentre M600- 10GK	10GK	
ThinkCentre M600- 10GL	10GL	
ThinkCentre M600- 10GM	10GM	
ThinkCentre M600- 10KG	10KG	
ThinkCentre M600- 10KH	10KH	
ThinkCentre M600- 10KJ	10KJ	

ThinkCentre M600-10KK	10KK	
ThinkCentre M60e-11LU	11LU	
ThinkCentre M60e-11LV	11LV	
ThinkCentre M60e-11LW	11LW	
ThinkCentre M60e-11LX	11LX	
ThinkCentre M60e-11LY	11LY	
ThinkCentre M60e-11M0	11M0	
ThinkCentre M60e-11M1	11M1	
ThinkCentre M60e-11M2	11M2	
ThinkCentre M625q-10TF	10TF	287.Not support Smart Power On function
ThinkCentre M625q-10TG	10TG	287.Not support Smart Power On function
ThinkCentre M625q-10TH	10TH	287.Not support Smart Power On function
ThinkCentre M625q-10TJ	10TJ	287.Not support Smart Power On function
ThinkCentre M625q-10TK	10TK	287.Not support Smart Power On function
ThinkCentre M625q-10TL	10TL	287.Not support Smart Power On function
ThinkCentre M625q-10UY	10UY	287.Not support Smart Power On function
ThinkCentre M625q-10V0	10V0	287.Not support Smart Power On function
ThinkCentre M625q-10V1	10V1	287.Not support Smart Power On function

ThinkCentre M625q- 10V2	10V2	287.Not support Smart Power On function
ThinkCentre M630e- 10YM	10YM	
ThinkCentre M700- 10GQ	10GQ	
ThinkCentre M700- 10GR	10GR	
ThinkCentre M700- 10HY	10HY	
ThinkCentre M700- 10J0	10J0	
ThinkCentre M700- 10JM	10JM	
ThinkCentre M700- 10JN	10JN	
ThinkCentre M700- 10JQ	10JQ	
ThinkCentre M700- 10JR	10JR	
ThinkCentre M700- 10JS	10JS	
ThinkCentre M700- 10JT	10JT	
ThinkCentre M700- 10KL	10KL	
ThinkCentre M700- 10KM	10KM	
ThinkCentre M700z- 10EY	10EY	
ThinkCentre M700z- 10F1	10F1	
ThinkCentre M70a Gen 2-11K3 - ThinkCentre M70a Gen 2	11K3	

ThinkCentre M70a Gen 2-11K4 - ThinkCentre M70a Gen 2	11K4	
ThinkCentre M70a Gen 2-11K5 - ThinkCentre M70a Gen 2	11K5	
ThinkCentre M70a Gen 2-11K6 - ThinkCentre M70a Gen 2	11K6	
ThinkCentre M70a- 11CK	11CK	
ThinkCentre M70a- 11CL	11CL	
ThinkCentre M70a- 11E2	11E2	
ThinkCentre M70a- 11E3	11E3	
ThinkCentre M70c- 11GJ	11GJ	
ThinkCentre M70c- 11GK	11GK	
ThinkCentre M70c- 11GL	11GL	
ThinkCentre M70c- 11GM	11GM	
ThinkCentre M70q Gen 2-11MY - ThinkCentre M70q Gen 2	11MY	
ThinkCentre M70q Gen 2-11N0 - ThinkCentre M70q Gen 2	11N0	
ThinkCentre M70q Gen 2-11N3 - ThinkCentre M70q Gen 2	11N3	



ThinkCentre M70q Gen 2-11N4 - ThinkCentre M70q Gen 2	11N4	
ThinkCentre M70q- 11DT	11DT	
ThinkCentre M70q- 11DU	11DU	
ThinkCentre M70q- 11DV	11DV	
ThinkCentre M70q- 11DW	11DW	
ThinkCentre M70s Gen 2-11M5	11M5	
ThinkCentre M70s Gen 2-11M6	11M6	
ThinkCentre M70s Gen 2-11M9	11M9	
ThinkCentre M70s Gen 2-11MA	11MA	
ThinkCentre M70s Gen 3-11T7-ThinkCentre M70s Gen 3	11T7	
ThinkCentre M70s Gen 3-11T8-ThinkCentre M70s Gen 3	11T8	
ThinkCentre M70s Gen 3-11TB-ThinkCentre M70s Gen 3	11TB	
ThinkCentre M70s Gen 3-11TC-ThinkCentre M70s Gen 3	11TC	
ThinkCentre M70s Gen 3-11X8-ThinkCentre M70s Gen 3	11X8	

ThinkCentre M70s Gen 3-11XG-ThinkCentre M70s Gen 3	11XG	
ThinkCentre M70s- 11DB	11DB	
ThinkCentre M70s- 11DC	11DC	
ThinkCentre M70s- 11EW	11EW	
ThinkCentre M70s- 11EX	11EX	
ThinkCentre M70t Gen 2-11M3	11M3	
ThinkCentre M70t Gen 2-11M4	11M4	
ThinkCentre M70t Gen 2-11M7	11M7	
ThinkCentre M70t Gen 2-11M8	11M8	
ThinkCentre M70t Gen 3-11T5-ThinkCentre M70t Gen 3	11T5	
ThinkCentre M70t Gen 3-11T6-ThinkCentre M70t Gen 3	11T6	
ThinkCentre M70t Gen 3-11T9-ThinkCentre M70t Gen 3	11T9	
ThinkCentre M70t Gen 3-11TA-ThinkCentre M70t Gen 3	11TA	
ThinkCentre M70t Gen 3-11X3-ThinkCentre M70t Gen 3	11X3	

ThinkCentre M70t Gen 3-11XE-ThinkCentre M70t Gen 3	11XE	
ThinkCentre M70t-11D9	11D9	
ThinkCentre M70t-11DA	11DA	
ThinkCentre M70t-11EU	11EU	
ThinkCentre M70t-11EV	11EV	
ThinkCentre M710e-10UQ	10UQ	287.Not support Smart Power On function
ThinkCentre M710e-10UR	10UR	287.Not support Smart Power On function
ThinkCentre M710q-10MQ	10MQ	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710q-10MR	10MR	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710q-10MS	10MS	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710q-10MT	10MT	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710q-10N3	10N3	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710q-10QR	10QR	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M710s-10M7	10M7	287.Not support Smart Power On function

ThinkCentre M710s- 10M8	10M8	287.Not support Smart Power On function
ThinkCentre M710s- 10NC	10NC	287.Not support Smart Power On function
ThinkCentre M710s- 10QT	10QT	287.Not support Smart Power On function
ThinkCentre M710t- 10M9	10M9	287.Not support Smart Power On function
ThinkCentre M710t- 10MA	10MA	287.Not support Smart Power On function
ThinkCentre M710t- 10NB	10NB	287.Not support Smart Power On function
ThinkCentre M710t- 10QK	10QK	287.Not support Smart Power On function
ThinkCentre M715q- 10M2	10M2	
ThinkCentre M715q- 10M3	10M3	
ThinkCentre M715q- 10M4	10M4	
ThinkCentre M715q- 10M5	10M5	
ThinkCentre M715q- 10RA	10RA	287.Not support Smart Power On function
ThinkCentre M715q- 10RB	10RB	287.Not support Smart Power On function
ThinkCentre M715q- 10RC	10RC	287.Not support Smart Power On function
ThinkCentre M715q- 10RD	10RD	287.Not support Smart Power On function
ThinkCentre M715q- 10VG	10VG	
ThinkCentre M715q- 10VH	10VH	
ThinkCentre M715q- 10VJ	10VJ	

ThinkCentre M715q- 10VK	10VK	
ThinkCentre M715q- 10VL	10VL	
ThinkCentre M715q- 10VM	10VM	
ThinkCentre M715q- 10VN	10VN	
ThinkCentre M715q- 10VQ	10VQ	
ThinkCentre M715s- 10MB	10MB	287.Not support Smart Power On function
ThinkCentre M715s- 10MC	10MC	287.Not support Smart Power On function
ThinkCentre M715t- 10MD	10MD	287.Not support Smart Power On function
ThinkCentre M715t- 10ME	10ME	287.Not support Smart Power On function
ThinkCentre M720e- 11BD	11BD	
ThinkCentre M720e- 11BE	11BE	
ThinkCentre M720q- 10T7	10T7	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720q- 10T8	10T8	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720q- 10T9	10T9	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720q- 10TA	10TA	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .

ThinkCentre M720q- 10TC	10TC	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720s- 10ST	10ST	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720s- 10SU	10SU	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720s- 10SV	10SV	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720t- 10SQ	10SQ	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720t- 10SR	10SR	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M720t- 10SS	10SS	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M725s- 10VT	10VT	
ThinkCentre M725s- 10VU	10VU	
ThinkCentre M73p- 10K9	10K9	
ThinkCentre M73p- 10KA	10KA	
ThinkCentre M73p- 10KB	10KB	
ThinkCentre M73p- 10KC	10KC	
ThinkCentre M73z- 10BB	10BB	

ThinkCentre M73z- 10BC	10BC	
ThinkCentre M75n- 11BS	11BS	
ThinkCentre M75n- 11BT	11BT	
ThinkCentre M75n- 11BU	11BU	
ThinkCentre M75n- 11BV	11BV	
ThinkCentre M75n- 11BW	11BW	
ThinkCentre M75n- 11BX	11BX	
ThinkCentre M75n- 11G4	11G4	
ThinkCentre M75n- 11G5	11G5	
ThinkCentre M75n- 11G6	11G6	
ThinkCentre M75n- 11G7	11G7	
ThinkCentre M75n- 11GW	11GW	
ThinkCentre M75n- 11GX	11GX	
ThinkCentre M75q Gen 2-11JJ	11JJ	
ThinkCentre M75q Gen 2-11JK	11JK	
ThinkCentre M75q Gen 2-11JL	11JL	
ThinkCentre M75q Gen 2-11JM	11JM	
ThinkCentre M75q-1- 11A4	11A4	

ThinkCentre M75q-1- 11A5	11A5	
ThinkCentre M75q-1- 11A6	11A6	
ThinkCentre M75q-1- 11A7	11A7	
ThinkCentre M75s Gen 2-11R7 - ThinkCentre M75s Gen 2	11R7	
ThinkCentre M75s Gen 2-11R8 - ThinkCentre M75s Gen 2	11R8	
ThinkCentre M75s Gen 2-11R9 - ThinkCentre M75s Gen 2	11R9	
ThinkCentre M75s Gen 2-11RA - ThinkCentre M75s Gen 2	11RA	
ThinkCentre M75s Gen 2-MT	11JA	
	11JB	
	11JC	
	11JD	
ThinkCentre M75s-1- 11A9	11A9	
ThinkCentre M75s-1- 11AA	11AA	
ThinkCentre M75s-1- 11AV	11AV	
ThinkCentre M75s-1- 11AW	11AW	
ThinkCentre M75t Gen 2-11KB	11KB	
ThinkCentre M75t Gen 2-11KC	11KC	



ThinkCentre M75t Gen 2-11KD	11KD	
ThinkCentre M75t Gen 2-11KE	11KE	
ThinkCentre M75t Gen 2-11RB - ThinkCentre M75t Gen 2	11RB	
ThinkCentre M75t Gen 2-11RC - ThinkCentre M75t Gen 2	11RC	
ThinkCentre M75t Gen 2-11RD - ThinkCentre M75t Gen 2	11RD	
ThinkCentre M75t Gen 2-11RE - ThinkCentre M75t Gen 2	11RE	
ThinkCentre M800- 10FV	10FV	
ThinkCentre M800- 10FW	10FW	
ThinkCentre M800- 10FX	10FX	
ThinkCentre M800- 10FY	10FY	
ThinkCentre M800z- 10ET	10ET	
ThinkCentre M800z- 10EU	10EU	
ThinkCentre M800z- 10EV	10EV	
ThinkCentre M800z- 10EW	10EW	
ThinkCentre M80q- 11DN	11DN	
ThinkCentre M80q- 11DQ	11DQ	

ThinkCentre M80q- 11DR	11DR	
ThinkCentre M80q- 11DS	11DS	
ThinkCentre M80q- 11Q9 - ThinkSmart M80q	11Q9	
ThinkCentre M80q- 11QA - ThinkSmart M80q	11QA	
ThinkCentre M80s- 11CU	11CU	
ThinkCentre M80s- 11CV	11CV	
ThinkCentre M80s- 11EM	11EM	
ThinkCentre M80s- 11EN	11EN	
ThinkCentre M80t- 11CS	11CS	
ThinkCentre M80t- 11CT	11CT	
ThinkCentre M80t- 11EK	11EK	
ThinkCentre M80t- 11EL	11EL	
ThinkCentre M810z- 10NX	10NX	287.Not support Smart Power On function
ThinkCentre M810z- 10NY	10NY	287.Not support Smart Power On function
ThinkCentre M810z- 10Q0	10Q0	287.Not support Smart Power On function
ThinkCentre M810z- 10Q1	10Q1	287.Not support Smart Power On function
ThinkCentre M810z- 10Q2	10Q2	287.Not support Smart Power On function

ThinkCentre M820z- 10SC	10SC	
ThinkCentre M820z- 10SD	10SD	
ThinkCentre M83z- 10C2	10C2	
ThinkCentre M83z- 10C3	10C3	
ThinkCentre M900- 10FC	10FC	
ThinkCentre M900- 10FD	10FD	
ThinkCentre M900- 10FG	10FG	
ThinkCentre M900- 10FH	10FH	
ThinkCentre M900- 10FL	10FL	
ThinkCentre M900- 10FM	10FM	
ThinkCentre M900- 10FR	10FR	
ThinkCentre M900- 10FS	10FS	
ThinkCentre M900x- 10LX	10LX	
ThinkCentre M900x- 10LY	10LY	
ThinkCentre M900z- 10F2	10F2	
ThinkCentre M900z- 10F3	10F3	
ThinkCentre M900z- 10F4	10F4	
ThinkCentre M900z- 10F5	10F5	

ThinkCentre M90a Gen 2-11JY - ThinkCentre M90a Gen 2	11JY	
ThinkCentre M90a Gen 2-11K0 - ThinkCentre M90a Gen 2	11K0	
ThinkCentre M90a Gen 2-11K1 - ThinkCentre M90a Gen 2	11K1	
ThinkCentre M90a Gen 2-11K2 - ThinkCentre M90a Gen 2	11K2	
ThinkCentre M90a Gen 2-11MN - ThinkCentre M90a Gen 2	11MN	
ThinkCentre M90a- 11CD	11CD	
ThinkCentre M90a- 11CE	11CE	
ThinkCentre M90a- 11DY	11DY	
ThinkCentre M90a- 11E0	11E0	
ThinkCentre M90n-1- 11AD	11AD	
ThinkCentre M90n-1- 11AE	11AE	
ThinkCentre M90n-1- 11AF	11AF	
ThinkCentre M90n-1- 11AG	11AG	
ThinkCentre M90n-1- 11AH	11AH	
ThinkCentre M90n-1- 11AJ	11AJ	

ThinkCentre M90n-1- 11AK	11AK	
ThinkCentre M90n-1- 11AM	11AM	
ThinkCentre M90n-1- 11AS	11AS	
ThinkCentre M90q Gen 2-11MQ - ThinkCentre M90q Gen 2	11MQ	
ThinkCentre M90q Gen 2-11MR - ThinkCentre M90q Gen 2	11MR	
ThinkCentre M90q Gen 2-11MU - ThinkCentre M90q Gen 2	11MU	
ThinkCentre M90q Gen 2-11MV - Thinkcentre M90q Gen 2	11MV	
ThinkCentre M90q- 11CR	11CR	
ThinkCentre M90q- 11DG	11DG	
ThinkCentre M90q- 11DH	11DH	
ThinkCentre M90q- 11DJ	11DJ	
ThinkCentre M90q- 11DK	11DK	
ThinkCentre M90q- 11DL	11DL	
ThinkCentre M90q- 11EY	11EY	
ThinkCentre M90q- 11F0	11F0	

ThinkCentre M90s Gen 2-11L2 - ThinkCentre M90s Gen 2	11L2	
ThinkCentre M90s Gen 2-11L3 - ThinkCentre M90s Gen 2	11L3	
ThinkCentre M90s Gen 2-11L6 - ThinkCentre M90s Gen 2	11L6	
ThinkCentre M90s Gen 2-11L7 - ThinkCentre M90s Gen 2	11L7	
ThinkCentre M90s- 11D1	11D1	
ThinkCentre M90s- 11D2	11D2	
ThinkCentre M90s- 11D6	11D6	
ThinkCentre M90s- 11D7	11D7	
ThinkCentre M90t Gen 2-11L0 - ThinkCentre M90t Gen 2	11L0	
ThinkCentre M90t Gen 2-11L1 - ThinkCentre M90t Gen 2	11L1	
ThinkCentre M90t Gen 2-11L4 - ThinkCentre M90t Gen 2	11L4	
ThinkCentre M90t Gen 2-11L5 - ThinkCentre M90t Gen 2	11L5	
ThinkCentre M90t- 11CY	11CY	
ThinkCentre M90t- 11D0	11D0	

ThinkCentre M90t- 11D4	11D4	
ThinkCentre M90t- 11D5	11D5	
ThinkCentre M910q- 10MU	10MU	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910q- 10MV	10MV	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910q- 10MW	10MW	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910q- 10MX	10MX	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910q- 10N4	10N4	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910q- 10QN	10QN	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910s- 10MK	10MK	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910s- 10ML	10ML	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910s- 10NA	10NA	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910s- 10QM	10QM	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .

ThinkCentre M910t-10MM	10MM	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910t-10MN	10MN	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910t-10N9	10N9	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910t-10QL	10QL	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkCentre M910x-10MY	10MY	287.Not support Smart Power On function
ThinkCentre M910x-10N0	10N0	287.Not support Smart Power On function
ThinkCentre M910x-10N1	10N1	287.Not support Smart Power On function
ThinkCentre M910x-10N2	10N2	287.Not support Smart Power On function
ThinkCentre M910x-10QQ	10QQ	287.Not support Smart Power On function
ThinkCentre M910x-10R4	10R4	287.Not support Smart Power On function
ThinkCentre M910z-10NR	10NR	287.Not support Smart Power On function
ThinkCentre M910z-10NS	10NS	287.Not support Smart Power On function
ThinkCentre M910z-10NT	10NT	287.Not support Smart Power On function
ThinkCentre M910z-10NU	10NU	287.Not support Smart Power On function
ThinkCentre M910z-10NV	10NV	287.Not support Smart Power On function
ThinkCentre M910z-10NW	10NW	287.Not support Smart Power On function



ThinkCentre M920q- 10RR	10RR	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920q- 10RS	10RS	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920q- 10RT	10RT	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920q- 10RU	10RU	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920q- 10V8	10V8	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920s- 10SJ	10SJ	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920s- 10SK	10SK	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920s- 10U2	10U2	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920s- 10U3	10U3	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920t- 10SF	10SF	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920t- 10SG	10SG	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920t- 10U0	10U0	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .

ThinkCentre M920t-10U1	10U1	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920x-10S0	10S0	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920x-10S1	10S1	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920x-10S2	10S2	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920x-10S3	10S3	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkCentre M920z-10S6	10S6	
ThinkCentre M920z-10S7	10S7	
ThinkCentre M93z-10AC	10AC	
ThinkCentre M93z-10AD	10AD	
ThinkCentre M93z-10AE	10AE	
ThinkCentre M93z-10AF	10AF	
ThinkCentre X1-10HT	10HT	
ThinkCentre X1-10HU	10HU	
ThinkCentre X1-10JW	10JW	
ThinkCentre X1-10JX	10JX	
ThinkCentre X1-10JY	10JY	
ThinkCentre X1-10K0	10K0	

ThinkCentre X1-10KE	10KE	
ThinkCentre X1-10KF	10KF	
ThinkCentre neo 30a 22 Gen 3-ThinkCentre neo 30a 22 Gen 3	12B1	
ThinkCentre neo 30a 24 Gen 3-ThinkCentre neo 30a 24 Gen 3	12B0	
ThinkCentre neo 50s Gen 3-11SW - ThinkCentre neo 50s Gen 3	11SW	
ThinkCentre neo 50s Gen 3-11SX - ThinkCentre neo 50s Gen 3	11SX	
ThinkCentre neo 50s Gen 3-11SY - ThinkCentre neo 50s Gen 3	11SY	
ThinkCentre neo 50s Gen 3-11T0 - ThinkCentre neo 50s Gen 3	11T0	
ThinkCentre neo 50t Gen 3-	11SC	
	11SD	
	11SF	
ThinkCentre neo 50t Gen 3-null	11SE	
ThinkEdge SE30-11NA - ThinkEdge SE30	11NA	
ThinkEdge SE30-11NB - ThinkEdge SE30	11NB	

ThinkEdge SE50-11RH - ThinkEdge SE50	11RH	
ThinkEdge SE50-11RJ - ThinkEdge SE50	11RJ	
ThinkPad 11e 2nd Generation-20E5 MT	20E5	
ThinkPad 11e 2nd Generation-20E6 MT	20E6	
ThinkPad 11e 2nd Generation-20E7 MT	20E7	
ThinkPad 11e 2nd Generation-20E8 MT	20E8	
ThinkPad 11e 2nd Generation-20ED MT	20ED	
ThinkPad 11e 2nd Generation-20EE MT	20EE	
ThinkPad 11e 3rd Generation-20G8 MT	20G8	
ThinkPad 11e 3rd Generation-20G9 MT	20G9	
ThinkPad 11e 3rd Generation-20GA MT	20GA	
ThinkPad 11e 3rd Generation-20GB MT	20GB	
ThinkPad 11e 3rd Generation-20GC MT	20GC	
ThinkPad 11e 3rd Generation-20GD MT	20GD	
ThinkPad 11e 3rd Generation-20GE MT	20GE	
ThinkPad 11e 3rd Generation-20GF MT	20GF	
ThinkPad 11e 4th Generation-20HS MT	20HS	
ThinkPad 11e 4th Generation-20HT MT	20HT	

ThinkPad 11e 4th Generation-20HU MT	20HU	
ThinkPad 11e 4th Generation-20HV MT	20HV	
ThinkPad 11e 4th Generation-20HW MT	20HW	371. Hotkey is not working under Chrome system
ThinkPad 11e 4th Generation-20HX MT	20HX	371. Hotkey is not working under Chrome system
ThinkPad 11e 4th Generation-20HY MT	20HY	371. Hotkey is not working under Chrome system
ThinkPad 11e 4th Generation-20J0 MT	20J0	371. Hotkey is not working under Chrome system
ThinkPad 11e 5th Generation-20LM MT	20LM	
ThinkPad 11e 5th Generation-20LN MT	20LN	
ThinkPad 11e 5th Generation-20LQ MT	20LQ	
ThinkPad 11e 5th Generation-20LR MT	20LR	
ThinkPad 13 1st Generation-20GJ MT	20GJ	
ThinkPad 13 1st Generation-20GK MT	20GK	
ThinkPad 13 1st Generation-20GL MT	20GL	371. Hotkey is not working under Chrome system
ThinkPad 13 1st Generation-20GM MT	20GM	371. Hotkey is not working under Chrome system
ThinkPad 13 2nd Generation-20J1 MT	20J1	
ThinkPad 13 2nd Generation-20J2 MT	20J2	
ThinkPad A475-20KL MT	20KL	
ThinkPad A475-20KM MT	20KM	

ThinkPad L14-20U1 MT 2020	20U1	
ThinkPad L14-20U2 MT 2020	20U2	
ThinkPad L15-20U3 MT 2020	20U3	
ThinkPad L15-20U4 MT 2020	20U4	
ThinkPad P1 3rd Generation-20TH MT 2020	20TH	
ThinkPad P1 3rd Generation-20TJ MT 2020	20TJ	
ThinkPad P14s-20S4 MT 2020	20S4	
ThinkPad P14s-20S5 MT 2020	20S5	
ThinkPad P15-20ST MT 2020	20ST	
ThinkPad P15-20SU MT 2020	20SU	
ThinkPad P15g-20UR MT 2020	20UR	
ThinkPad P15g-20US MT 2020	20US	
ThinkPad P15v-20TQ MT 2020	20TQ	
ThinkPad P15v-20TR MT 2020	20TR	
ThinkPad P17-20SN MT 2020	20SN	
ThinkPad P17-20SQ MT 2020	20SQ	
ThinkPad S1 Yoga 12- 20DK MT	20DK	

ThinkPad S1 Yoga 12- 20DL MT	20DL	
ThinkPad T14-20S0 MT 2020	20S0	
ThinkPad T14-20S1 MT 2020	20S1	
ThinkPad T14-20S2 MT 2020 HC	20S2	
ThinkPad T14-20S3 MT 2020 HC	20S3	
ThinkPad T14s-20T0 MT 2020	20T0	
ThinkPad T14s-20T1 MT 2020	20T1	
ThinkPad T15-20S6 MT 2020	20S6	
ThinkPad T15-20S7 MT 2020	20S7	
ThinkPad T15p-20TM MT 2020	20TM	
ThinkPad T15p-20TN MT 2020	20TN	
ThinkPad W541-20EF MT	20EF	
ThinkPad W541-20EG MT	20EG	
ThinkPad W550s-20E1 MT	20E1	
ThinkPad W550s-20E2 MT	20E2	
ThinkPad X1 Tablet- 20GG MT	20GG	
ThinkPad X1 Tablet- 20GH MT	20GH	
ThinkPad X1 Tablet- 20JB MT	20JB	

ThinkPad X1 Tablet- 20JC MT	20JC	
ThinkPad X270-20KC MT	20KC	
ThinkPad X270-20KD MT	20KD	
ThinkPad Yoga 260- 20FD MT	20FD	
ThinkPad Yoga 260- 20FE MT	20FE	
ThinkPad Yoga 260- 20GS MT	20GS	
ThinkPad Yoga 260- 20GT MT	20GT	
ThinkPad Yoga 370- 20JH MT	20JH	
ThinkPad Yoga 370- 20JJ MT	20JJ	
ThinkStation P310- 30AS	30AS	
ThinkStation P310- 30AT	30AT	
ThinkStation P310- 30AU	30AU	
ThinkStation P310- 30AV	30AV	
ThinkStation P310- 30AY	30AY	
ThinkStation P310- 30B0	30B0	
ThinkStation P320 Tiny-30C1	30C1	290.To enable Smart Power On Function, and update download and update firmware at:  <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkStation P320 Tiny-30C2	30C2	290.To enable Smart Power On Function, and update download and update firmware at:  <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .



ThinkStation P320 Tiny-30C3	30C3	290.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS500739">https://support.lenovo.com/us/en/downloads/DS500739</a> .
ThinkStation P320- 30BG	30BG	
ThinkStation P320- 30BH	30BH	
ThinkStation P320- 30BJ	30BJ	
ThinkStation P320- 30BK	30BK	
ThinkStation P320- 30BR	30BR	
ThinkStation P320- 30BS	30BS	
ThinkStation P320- 30BT	30BT	
ThinkStation P330 Tiny-30CE	30CE	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkStation P330 Tiny-30CF	30CF	289.To enable Smart Power On Function, and update download and update firmware at: <a href="https://support.lenovo.com/us/en/downloads/DS504774">https://support.lenovo.com/us/en/downloads/DS504774</a> .
ThinkStation P330- 30C5	30C5	
ThinkStation P330- 30C6	30C6	
ThinkStation P330- 30C7	30C7	
ThinkStation P330- 30C8	30C8	
ThinkStation P330- 30C9	30C9	
ThinkStation P330- 30CA	30CA	

ThinkStation P330- 30CY	30CY	
ThinkStation P330- 30D0	30D0	
ThinkStation P330- 30D1	30D1	
ThinkStation P330- 30D2	30D2	
ThinkStation P330- 30D3	30D3	
ThinkStation P330- 30D4	30D4	
ThinkStation P340 Tiny-30DE	30DE	
ThinkStation P340 Tiny-30DF	30DF	
ThinkStation P340 Tiny-30DG	30DG	
ThinkStation P340 Tiny-30DR	30DR	
ThinkStation P340 Tiny-30DS	30DS	
ThinkStation P340- 30DH	30DH	
ThinkStation P340- 30DJ	30DJ	
ThinkStation P340- 30DK	30DK	
ThinkStation P340- 30DL	30DL	
ThinkStation P340- 30DM	30DM	
ThinkStation P340- 30DN	30DN	
ThinkStation P348- 30EQ	30EQ	

ThinkStation P348- 30ER	30ER	
ThinkStation P350 Tiny-30EF	30EF	
ThinkStation P350 Tiny-30EG	30EG	
ThinkStation P350 Tiny-30EH	30EH	
ThinkStation P350 Tiny-30EJ	30EJ	
ThinkStation P350- 30E3	30E3	
ThinkStation P350- 30E4	30E4	
ThinkStation P350- 30E5	30E5	
ThinkStation P350- 30E6	30E6	
ThinkStation P410- 30B2	30B2	
ThinkStation P410- 30B3	30B3	
ThinkStation P510- 30B4	30B4	
ThinkStation P510- 30B5	30B5	
ThinkStation P520- 30BE	30BE	
ThinkStation P520- 30BF	30BF	
ThinkStation P520- 30BN	30BN	
ThinkStation P520- 30BP	30BP	
ThinkStation P520- 30BQ	30BQ	

ThinkStation P520c- 30BX	30BX	
ThinkStation P520c- 30BY	30BY	
ThinkStation P520c- 30C0	30C0	
ThinkStation P620- 30E0	30E0	
ThinkStation P620- 30E1	30E1	
ThinkStation P710- 30B6	30B6	
ThinkStation P710- 30B7	30B7	
ThinkStation P720- 30BA	30BA	
ThinkStation P720- 30BB	30BB	
ThinkStation P720- 30BU	30BU	
ThinkStation P910- 30B8	30B8	
ThinkStation P910- 30B9	30B9	
ThinkStation P920- 30BC	30BC	
ThinkStation P920- 30BD	30BD	
ThinkStation P920- 30BV	30BV	
Thinkbook 13s-IWL-MT 20R9	20R9	
Thinkbook 14s-IWL-MT 20RM	20RM	
X1 Carbon 3rd Generation-20BS MT	20BS	

X1 Carbon 3rd Generation-20BT MT	20BT	
X1 Carbon 4th Generation-20FB MT	20FB	
X1 Carbon 4th Generation-20FC MT	20FC	
X1 Carbon 5th Generation-20HQ MT	20HQ	
X1 Carbon 5th Generation-20HR MT	20HR	
X1 Carbon 5th Generation-20K3 MT	20K3	
X1 Carbon 5th Generation-20K4 MT	20K4	
X1 Carbon 6th Generation-20KG MT	20KG	
X1 Carbon 6th Generation-20KH MT	20KH	
X1 Carbon 7th Generation-20QD MT	20QD	
X1 Carbon 7th Generation-20QE MT	20QE	
X1 Carbon 7th Generation-20R1 MT	20R1	
X1 Carbon 7th Generation-20R2 MT	20R2	
X1 Carbon 8th Generation-20U9 MT 2020	20U9	
X1 Carbon 8th Generation-20UA MT 2020	20UA	
X1 Carbon 9th Generation-20XW - X1 Carbon Gen 9	20XW	

X1 Carbon 9th Generation-20XX - X1 Carbon Gen 9	20XX	
X1 Extreme 1st Generation-20MF MT	20MF	
X1 Extreme 1st Generation-20MG MT	20MG	
X1 Extreme 2nd Generation-20QV MT	20QV	
X1 Extreme 2nd Generation-20QW MT	20QW	
X1 Extreme 3rd Generation-20TK MT 2020	20TK	
X1 Extreme 3rd Generation-20TL MT 2020	20TL	
X1 Extreme G4-20Y5 - X1 Extreme Gen 4	20Y5	
X1 Extreme G4-20Y6 - X1 Extreme Gen 4	20Y6	
X1 Yoga 1st Generation-20FQ MT	20FQ	
X1 Yoga 1st Generation-20FR MT	20FR	
X1 Yoga 2nd Generation-20JD MT	20JD	
X1 Yoga 2nd Generation-20JE MT	20JE	
X1 Yoga 2nd Generation-20JF MT	20JF	
X1 Yoga 2nd Generation-20JG MT	20JG	
X1 Yoga 3rd Generation-RAVEN-3.0 20LD MT	20LD	

X1 Yoga 3rd Generation-RAVEN-3.0 20LE MT	20LE	
X1 Yoga 3rd Generation-RAVEN-3.0 20LF MT	20LF	
X1 Yoga 3rd Generation-RAVEN-3.0 20LG MT	20LG	
X1 Yoga 4th Generation-20QF MT	20QF	
X1 Yoga 4th Generation-20QG MT	20QG	
X1 Yoga 4th Generation-20SA MT	20SA	
X1 Yoga 4th Generation-20SB MT	20SB	
X1 Yoga 5th Generation-20UB MT 2020	20UB	
X1 Yoga 5th Generation-20UC MT 2020	20UC	
X1 Yoga 6th Generation-20XY - X1 Yoga Gen 6	20XY	
X1 Yoga 6th Generation-20Y0 - X1 Yoga Gen 6	20Y0	
X13 AMD G1-20UF MT 2020	20UF	
X13 AMD G1-20UG MT 2020	20UG	
X13 AMD G2-20XH - X13 AMD Gen 2	20XH	

X13 AMD G2-20XJ - X13 AMD Gen 2	20XJ	
X13 G1-20T2 MT 2020	20T2	
X13 G1-20T3 MT 2020	20T3	
X13 G2-20WK - X13 Gen 2	20WK	
X13 G2-20WL - X13 Gen 2	20WL	
X13 Yoga 2nd Generation-20W8 MT 2021	20W8	
X13 Yoga 2nd Generation-20W9 MT 2021	20W9	
X13 Yoga-20SX MT 2020	20SX	
X13 Yoga-20SY MT 2020	20SY	
X250-20CL MT	20CL	
X250-20CM MT	20CM	
X260-20F5MT	20F5	
X260-20F6 MT	20F6	
X270-20HM MT	20HM	
X270-20HN MT	20HN	
X270-20K5 MT	20K5	
X270-20K6 MT	20K6	
X280-20KE MT	20KE	
X280-20KF MT	20KF	
X380 Yoga-STORM-3.0 20LH MT	20LH	



X380 Yoga-STORM-3.0 20LJ MT	20LJ	
X390 Yoga-20NN MT	20NN	
X390 Yoga-20NQ MT	20NQ	
X390-20Q0 MT	20Q0	
X390-20Q1 MT	20Q1	
X390-20SC MT	20SC	
X390-20SD MT	20SD	
X395-20NL MT	20NL	
X395-20NM MT	20NM	
Yoga 14-20FY MT	20FY	
Yoga 460-20EL MT	20EL	
Yoga 460-20EM MT	20EM	
Yoga 6 13ALC6-82ND - Yoga 6 13ALC6	82ND	
Yoga 7 14ACN6-82N7 - Yoga 7 14ACN6	82N7	
Yoga 9 14IAP7-82LU - Yoga 9 14IAP7	82LU	
Yoga Slim 7 Pro 14ACH5 D-82NJ - Yoga Slim 7 Pro 14ACH5 D	82NJ	
Yoga Slim 7 Pro 14ACH5 O-82N5 - Yoga Slim 7 Pro 14ACH5 O	82N5	
Yoga Slim 7 Pro 14ACH5 OD-82NK - Yoga Slim 7 Pro 14ACH5 OD	82NK	

Yoga Slim 7 Pro 14IHU5 O-82NH - Yoga Slim 7 Pro 14IHU5 O	82NH	
Yoga Slim 7 Pro 16ACH6-82QQ - Yoga Slim 7 Pro 16ACH6	82QQ	